

Contents: Flebi Pluma bicycle, battery, charger.

Necessary Tools: Scissors and Cutter.

1. Remove the protective covers.
2. Insert the seatpost.
3. Unfold the handlebar.
4. Connect the cable to the bottom of the seatpost.
5. Adjust the saddle and handlebar, always respecting the insertion marks.
6. Unfold the pedals.
7. Connect the charger to the battery just below the saddle after first removing the small cap.
8. Charge the battery until the charger light turns green.
9. Make sure the tyres are at the correct pressure (2.5 bar / 36 PSI). Adjust if necessary.
10. Perform the required settings on the display. **(IMAGE 01)**

SWITCHING ON AND OFF

1. **Switch on:** Press and hold the "On/Off" button for 2 s until the start-up screen appears.
2. **Switch off:** Press and hold the same button for 2 s or leave idle for 5 min (speed 0).
3. **Welcome screen:** 2 s before displaying the basic interface.

BUTTONS

1. **Power button:** Hold the power button for 2 seconds to turn the system on or off.
2. **Mode button (M):** Used for switching between different types of information on the screen, such as speed, total distance (ODO), trip distance (TRIP), and more.
3. **"+" and "-" buttons:** Use these buttons to adjust the pedal assist level and navigate through the display options.

BASIC OPERATIONS

1. **Change assistance level (0-5):** press "+" or "-" to toggle.
2. **Change display:** briefly press "Mode" to toggle: TRIP - ODO - AVG - MAX - TRIP TIME.
3. **Minimum assistance" mode (6 km/h):** hold 'Mode' for 2 s to enter/exit minimum assistance.
4. **Front light:** hold "+" or "-" 1 s to switch on/off.

© IMAGE 01



TROUBLESHOOTING: ERROR CODES

1. **E30:** Communication failure; the display is not receiving valid data from the controller or the data is corrupted.
2. **Recommended solutions:**
 - A. Verify that the TX/RX lines are properly connected.
 - B. Check that cables and connectors are not loose or damaged.

